

Thermo Scientific AquaSensors™ RDO® Pro Sensor Nose Replacement Kit, Cat. No. RDN1

Instructions

1. Remove the existing O-ring from the sensor body.



2. Place a small amount of lubricant on your fingertips. Coat the entire O-ring with lubricant. Do not allow any dust or particles to get on the O-ring.
3. Place the new O-ring on the sensor body.
4. Use the lens wipe to remove any lubricant from the sensor body or RDO sensor cap.
5. Place the nose on the sensor body.

Kit Contents



©2009 Thermo Fisher Scientific Inc. All rights reserved. RDO is a registered trademark of In-Situ Inc., Fort Collins, CO USA. All other trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries.



Process Water Instruments

North America
166 Cummings Center
Beverly, MA 01915 USA
Toll Free: 1-800-225-1480
Tel: 1-978-232-6000
Dom. Fax: 1-978-232-6015
Int'l Fax: 978-232-6031

Europe
P.O. Box 254, 3860 AG Nijkerk
Wallerstraat 125K, 3862 BN
Nijkerk, Netherlands
Tel: (31) 033-2463887
Fax: (31) 033-2460832

Asia Pacific
Blk 55, Ayer Rajah Crescent
#04-16/24, Singapore 139949
Tel: 65-6778-6876
Fax: 65-6773-0836

www.thermo.com/processwater